





## **BLUESOLAR PWM LIGHT CHARGE CONTROLLERS**

BlueSolar PWM Light Charge Controllers are widely used to charge batteries with solar power. The PWM Controller is a switch that connects a solar array to the battery. The result is that the voltage of the array will be pulled down to near that of the battery.

## Features:

- · Load output with low-battery voltage disconnect function
- · Lighting control function, one timer only
- Two-digit seven-segment display for quick and easy setting of the load output functionality, including timer setting
- · Three-stage battery charging (bulk, absorption, float), not programmable
- · Load-output protected against overload and short-circuit
- · Protected against reverse-polarity connection of the solar array and the battery



BlueSolar PWM Light	12/24-5 Part No.: TBA	12/24-10 Part No.: T750020023	12/24-20 Part No.: T129616902	12/24-30 Part No.: TBA
Battery Voltage	12/24 V with automatic system voltage detection			
Rated Charge Current	5 A	10 A	20 A	30 A
Automatic Load Disconnect	Yes			
Maximum Solar Voltage	28 V/55 V <sup>(f)</sup>			
Self-Consumption	< 10 mA			
Load Output	Manual control + low-voltage disconnect			
Protection	Battery reverse polarity (fuse); Output short-circuit; Over temperature			
Overload Protection	Shut down after 60 s in case of 130% load			
	Shut down after 5 s in case of 160% load			
	Short-circuit: immediate shut down			
Grounding	Common positive			
Operating Temp. Range	-20 °C to +50 °C (full load)			
Humidity (Non-Condensing)	Max. 95%			
		BATTERY		
Charge Voltage 'Absorption'	14.2 V/28.4 V			
Charge Voltage 'Float'	13.8 V/27.6 V			
Low Voltage Load Disconnect	11.2 V/22.4 V			
Low Voltage Load Reconnect	12.6 V/25.2 V (manual) 13.1 V/26.2 V (automatic)			
		ENCLOSURE		
Protection Class	IP20			
Terminal Size	5 mm/AWG10			
Weight	0.15 kg			0.2 kg
Dimensions (h x w x d)	70 x 133 x 33.5 mm			
STANDARDS				
Safety	IEC 62109-1			
EMC	EN 61000-6-1, EN 61000-6-3, ISO 7637-2			

4

POWER SUPPLY

AutoTech | RiskTech | ManTech | ServTech | FleetTech | EngTech

Eastern Cape - Port Elizabeth T: +27 (0)82 450 6596

Free State - Bloemfontein T: +27 (0)63 257 0505

Gauteng - Bedfordview (FleetTech) T: +27 (0)10 329 0932

Gauteng - Jet Park (HQ) T: +27 (0)11 823 5650

KwaZulu Natal - Pinetown T: +27 (0)31 303 4129

Mpumalanga - Middelburg T: +27 (0)13 692 8132

Northern Cape - Kathu T: +27 (0)53 723 3415

North West - Rustenburg T: +27 (0)14 596 5257

Western Cape - Cape Town T: +27 (0)21 945 1453

Botswana - Gaborone **T:** +267 399 4150

Mozambique - Tete T: +258 252 20666

Zambia - Kitwe T: +26 (0)21 222 5338



Delivering Optimal Uptime!