

# **PORTABLE MINING AXLE SCALE**

## Flexible weighing where you haul!

The mining truck axle scale systems are constructed for longevity in order to provide many years of consistent, dependable service while reducing on-going maintenance requirements. The mining series of portable mining truck scales are used for earth foundations, allowing mine sites to transport their scales directly to their haulage assets.









### **SPECIFICATIONS**

#### **AXW-110: 110-TON PORTABLE AXLE SCALE**

- 110-Ton axle capacity
- Pad dimensions: 102.87 x 102.87 cm
- Aluminium or steel construction
- Portable transport crate included
- Spare cabling included
- Water protected design
- Qty (2) pads (sold in pairs)

#### **AXM-300: 300-TON PORTABLE AXLE SCALE**

- 300-Ton axle capacity
- Pad dimensions: 238.76 x 213.36 cm
- Steel construction
- Lifting eyes
- Waterproof design
- Light weight for easy transport
- Qty (2) pads (sold in pairs)

#### **AXM-600: 600-TON PORTABLE AXLE SCALE**

- 600-Ton axle capacity
- Pad dimensions: 238.76 x 213.36 cm
- Steel construction
- Lifting eyes
- Waterproof design
- Light weight for easy transport
- Qty (4) pads

#### **AXM-800: 800-TON PORTABLE AXLE SCALE**

- 800-Ton axle capacity
- Pad dimensions: 240.03 x 398.78 cm
- Steel construction
- Lifting eyes
- Waterproof design
- Light weight for easy transport
- Qty (2) pads (sold in pairs)

This may not be a stock item. Please speak to your sales representative about lead times. Lead times, price and availability can only be determined on receipt of an official quote from our supplier. This can sometimes take up to 3 days.

South Africa, Gauteng, Jet Park - Head Office:

KwaZulu Natal:

**T:** +27 (0)31 303 4129

Northern Cape:

**T:** +27 (0)53 723 3415

North West:

**T:** +27 (0)14 596 5257

Mpumalanga:

**T:** +27 (0)13 692 8132

Western Cape:

Eastern Cape:

**T:** +27 (0)81 036 9111

T: +27 (0)21 945 1453

**T:** +27 (0)11 823 5650

Free State:

**T:** +27 (0)63 257 0505

Botswana, Gaborone:

**T:** +267 399 4150

**Botswana, Jwaneng: T:** +267 588 7617

Botswana, Letlhakane:

T: +267 297 8568

Mozambique, Tete:

**T:** +258 252 20666

Zambia, Kitwe:

**T:** +26 (0)21 222 5338

